



*Woodworking machinery at its best!*

## W791 3-Phase Switch Wiring Instructions

D.O.L Starter 3-Phase 415V, 50Hz, 1500w (2hp)

### Links (ready fitted to new units)

Red - 96 to L1/1 Lower  
Red - 95 to L1/1 Upper


### Motor Cable

Brown to 2  
Black to 4  
Grey to 6  
Green/Yellow to Earth

### Supply Cable

Brown to L1/1  
Black to L2/3  
Grey to L3/5  
Green/Yellow to Earth

L1/1 Upper    L1/1 Lower    L2/3 Upper    L3/5 Upper    Earth



2    4    6    96    95  
Lower Terminal    Earth