



Woodworking machinery at its best!

W792 3-Phase Switch Wiring Instructions

D.O.L Starter 3-Phase 415V, 50Hz, 2200w (3hp)

Links (ready fitted to new units)

Red - 96 to L1/1 Lower
Red - 95 to L1/1 Upper


Motor Cable

Black to 2
Black to 4
Black to 6
Green/Yellow to Earth

Supply Cable

Brown to L1/1
Black to L2/3
Grey to L3/5
Green/Yellow to Earth

L1/1 Upper L1/1 Lower L2/3 Upper L3/5 Upper Earth



2 4 6 96 95 Earth
Lower
Terminal